Quick Start Guide / Schnellstart Anleitung / Guía de inicio rápido / Quide de Démarrage Rapide / Guida Rapida

For better user experience, please keep the front and both sides of the camera lens away from objects reflective as glass, white wall etc, so that the picture function well without overexposure.

Make sure the camera has been placed in areas of good signal of the Wi-Fi, set it up away from somewhere might jamming signal as metal or microwave oven.

If this is a PTZ rotation type camera, do not twist the camera to force it to rotate, if you need to adjust the monitoring orientation, you can adjust it through the PT function of the mobile APP.

Turn on the Camera

Use the correct power adapter and connect it to the power Interface of the camera, and then wait a few minutes until the camera startup completed.

Reboot or Restore Factory Settings

Reconnect the power to reboot the camera.

Press and hold the reset button for 5 seconds, you will hear the "dong..." restart tone, then the camera will restore to factory settings.



Connect the Camera and Watch on the Phone

Download "CamHiPro" or "CamHi" from Google Play Store / Apple App Store or scan the QR code below to get APP information.



Android



Method 1: Connect with Wi-Fi

Some things you need to check first:

Please make sure that the wireless signal value of the camera installation location

is higher than 70% in the signal list of the camera, you can check it in APP later.

Connect the power to the camera(Do not connect the network cable), install or check the antenna of camera.

Enter your phone "Settings"-"WLAN" page, you can find the camera's hot spot in the WLAN list, if you do not find this hot spot, please reset the camera and wait 1 minute to find the hot spot, the hot spot name is "IPCAM-*****"(The symbol * represents a number, for example IPCAM-66666), the hot spot password is "01234567", connect it as shown below Shown: Quick Start Guide / Schnellstart Anleitung / Guía de inicio rápido / Quide de Démarrage Rapide / Guida Rapida

16:00

1 79% 🔳

No SIM 🗢	16:00	7 79% 🔳 י
Settings	WLAN	
WLAN		
 Bosesh-offic 	e	🛾 🗢 (i)
CHOOSE A NETWOR	!K	
CEO		₽ ╤ (j)
ChinaNet-En	Dx	a
ChinaNet-v4	dU	₽ 중 (j)
ChinaNet-Wr	۱Nr	₽ 중 (j)
НХМ		₽ ╤ (j)
IPCAM-2273	88	₽ 奈 (i)
TP-LINK_829	01	₽ 중 (j)
TP-LINK_FE5	6	₽ 중 (j)
UTT-HIPER_4	65A282B	∻ (i)
XHT		₽ 奈 (i)
Find hot a	-not of th	

Enter the password for "IPCAM-22/388"									
Cancel Enter Password					Jo	oin			
Pas	sswo	rd	••••	••••					
You can also access this WLAN network by bringing your iPhone near any iPhone, iPad, or Mac which has connected to this network and has you in their contacts.									
Passwords									
1	2	3	4	5	6	7	8	9	0
-	1	:	;	()	\$	&	@	"
#+=		•	ı		?	!	'		\bigotimes
F	BC		space					Joir	ň

Find hot spot of the camera "IPCAM-*****"

The hot spot password of the camera is "01234567"

No SIM	ŝ	19:17	1 8	34% —)
< Se	ttings	WLAN		
١	WLAN			0
 I 	PCAM-227388		₽ <	• (i)
СНО	OSE A NETWORK			
E	Bosesh-office		a 3	7 (i)
E	Bosesh-test0		Ę	F (j)
E	Bosesh-test1		₽ 3	• (i)
E	Bosesh-test2		4	• (i)
(ChinaNet-v4dU		A 3	• (i)
(ChinaNet-WnNr		a 3	r (j)
(ChinaNet-ZRfH		8	• (i)
ł	НХМ		a 3	• (i)
Ş	Sunengpai		a 3	• (i)
-	TP-LINK_8291		a 3	7 (i)
Со	nnected	notspot		

Then run APP "CamHiPro" and follow the steps below:

No SIM 奈



Quick Start Guide / Schnellstart Anleitung / Guía de inicio rápido / Quide de Démarrage Rapide / Guida Rapida										
No SIM 🗢	18:39	1 87% (),	No SIM 🗢	16:01	7 79% 🔳	No SIM 🗢	17:51	7 70% 🔳 ,		
〈 Back	AP equipment	\times	K Back	Device Information	\times	〈 Back	Wireless configuration	\times		
The current device AP hotspot mode is detected Hotspot device UID found:			FILL IN YOUR DEVICE INFORMATION UID: SSAA-227388-CABEA			Current de PLEASE CH CONFIGUR	Current deviceUID: SSAA-227388-CABEA PLEASE CHOOSE THE WIRELESS NETWORK CONFIGURATION YOU USE FREQUENTLY TO MAKE IT			
SSAA-227388-CABEA			username:	admin		EASIER FO BASIS	R YOU TO USE THE DEVICE ON A	. DAILY		
			password:	admin		Wireless name:	Bosesh-office	>		
Ye	s, I want to add this device	->				password	: *********			
Current network: To add another ne	IPCAM-227388 w device, first disconnect your phone	from this hotspot								
				Add to		Cont	igure wireless and add d	evices		
Click this d	"Yes, I want t evice"	to add	Click "Add to"			Choose your Wi-Fi and enter the password, then click "Configure wireless and add devices"				
No SIM 🗢	16:39	1 32% 🔲	No SIM 🗢	17:52	1 70% 🔳 ,	No SIM 🗢	16:52	🕫 75% 🔳 ,		
く Back	Select wireless	\times	< Back	Name setting	\times	=	Camera 믐	+		
SELECT THE ON THE DEVI NETWORK, T	NETWORK AND CONFIGURE I CENOTE:MAKE SURE THE SE HE CURRENT PHONE HAS BE AND LISED	IT FOR USE LECTED EN	A NAME	HAS BEEN ADDED SUCCESSFU	JLLY! GIVE IT	• Online	e			
UTT-HIPER	_465A282B		quick select	ion:			6			
Bosesh-tes singal:100%	t1 WPA2_TKIP		Living room	Bedroom Doorway	Baby room		×			
Bosesh-off singal:100%	ice WPA2_AES		Store	Corridor Hall	Office					
TP-LINK_82	291 WPA2 AFS					Camer	a SSAA-2273	88-CABEA		
XHT singal:100%	WPA2_AES			Added successfully				තු		
ChinaNet-v singal:100%	4dU WPA2_TKIP									
ChinaNet-V singal:98%	VnNr WPA2_TKIP									
ChinaNet-E singal:94%	nDx WPA2_TKIP									
Bosesh-tes singal:90%	t2									
ChinaNet-D singal:90%	WPA2_TKIP			confirm						
TP-LINK FE	56									
Find yo	our Wi-Fi and i	make	Name	the camera ar	id	Camera is added, click the online camera to watch				
sure its	s signal is high	er than	click "d	confirm"						
70%										
							1 14			

When the Wi-Fi connection is successful, you will hear the sound "ding..." from

camera, if not, please check your Wi-Fi password and reconfigure.

English / Deutsch / Español / Français / Italiano